
Implement taste and smell with nanosensors

Zhiyong Li HP Labs, Palo Alto, CA, USA zhiyong.li@hp.com

Microtechnology and semiconductor industry have revolutionalized modern life













San Bruno Fire









Pesticide residue?



Analysis of food contaminants in Lab



Extraction

Sample concentrator

Analysis (GCLC-MS)

Time-consuming: several hours (exclude sample shipping) Expensive tools: hundreds of thousands dollar Complicated: need professional operator (labor cost)



Safe, secure, sustainable world and people's well-being demand more sensors





Nanosensor is the solution to implement smell and taste (chemical sensing or chemosensation)

Potential application of smell and taste nanosensors

Food and agriculture: food contaminant test and monitoring,
 \$1.6billion market

Healthcare: Disease diagnostic, patient monitoring, multi-function test strips \$53billion IVD market

Drug regulations: supply monitoring, anti-counterfeiting, 5-10% of WW pharmaceutical annual sales of \$800billion is believed to be counterfeit

Chemical industry: industrial chemical monitoring


Government: environmental monitoring, security and defense applications, food, agriculture and drug regulations

R&D organizations: developing new apps




Silicon ChemFET Nanosensor

Low-cost high-value sensor technology for parallel detection of 100s – 1000s of bio-molecular species.



Sensing proton to DNA




© Copyright 2011 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice. HP confidential.

Z. Li, et al, Nanoletter, 2004, 4, 245



Smelling the hydrosulfide gas




I. Park, Z. Li et al, Nano Letters, 2007 and 2011



Surface Enhanced Raman Spectroscopy (SERS) – enabling "molecular fingerprinting"


Localized surface plasmon on nanostructure can enhance the Raman scattering process -- SERS



SERS Enhancement Factor $\propto |E(\omega)|^2 |E(\omega')|^2$

also approx. to ~ $|\mathsf{E}|^4$


Electromagnetic field induced EF: 10⁶ - 10¹²





Surface Enhanced Raman Scattering (SERS)

1974 – M. Fleischman studied pyridine on roughened silver with increased surface area.


1977 – Rick Van Duyne and Alan Creighton reported enhancement of $\sim 10^5$ - 10^6 -- much too large to account for, by the increased surface area alone.








HP's SERS Technology Evolution



Molecular Trapped in SERS "hot-spots"



Hu, M. et. al. J. Am. Chem. Soc. 2010, 132, 12820.



Top-down meets self-assembly


— the leap from stochastic to deterministic SERS structures

Advantages of nanofinger structures

- Leverage advantages from both top-down and bottomup approaches – No need of costly critical dimension control.
- Easy scale-up for large area uniformity and reliable hot spots Roll-to-roll plastic fab.
- Micro-capillary driven "finger" closing Easy for fluidic interface, no power nor complicated controls needed.
- Molecule self-limiting of the gap sizes, as small as subnm – Physical limit of the smallest separation manufacturable, hence strongest coupling effect.
 Active molecule trapping by the fingers – Molecular
- tweezer with build-in sensing functionality.



CAN WE DESIGN FINGER SYMMETRY?




© Copyright 2011 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice. HP confidential.

Ou, F. S. et. al. Nano Letters, 2011, 11, 2538-2542.




SERS of nanofinger of different symmetry



Ou, F. S. et. al. Nano Letters, 2011, 11, 2538-2542.








Demonstration A:

Melamine sensing with HP nanofinger SERS: >10,000× better than competitors





Melamine contamination in milk, 300,000 victims in China 2008



max. amount in infant formula (FDA):

1 mg/kg (1 part per million)






100 parts per trillion

Demonstration B:

Chlropyrifos sensing with HP nanofinger SERS: >1,000× lower than EPA regulation



Chlropyrifos, is a **neurotoxin**, **carcinogen**, once popular pesticide used worldwide, and the residue can be found in vegetables, fruits, etc.



35 parts per trillion

EPA regulation: 0.1 parts per million on citrus fruits

